



	ISA110 LIMITED EDITION
88888	Serial No
8888888	Signed:
X8/8/8/8/8/8	Phil Dudderidge, Director Simon Blackwood, Director
	Rob Jenkins, Head of Sound

Thank you for purchasing the ISA110 brought to you by the Focusrite team — Trevor, Peter, Martin, Helen, Mick, Phil, Chris, Micky, Pauline, Jo, Chris, Nathan, Rob, Peter, Simon and Giles.

The chaps at Focusrite are a jolly hard working bunch and take a great deal of pride in designing, building and delivering the best audio products around; we hope your new Focusrite unit lives up to that reputation, and that you enjoy many years of productive recording.

If you would like to tell us about your recording experiences then email us at: sales@focusrite.com

10 Frence Job. Norman Juin felt Gis Martin Giles Holon Sine Phil Mick. Chris july Fester

The FocusriteTeam

Contents

Important Safety Instructions
Power Connections
Signal Connections
Getting to Know the ISA1104-5
Applications
Specifications
Warranty
Focusrite Distributors

Important Safety Instructions

Read all of these instructions and save them for future reference. Follow all warnings and instructions marked on the unit

- Do not obstruct air vents in the rear panel.
 Do not insert objects through any apertures.
- Do not use a damaged or frayed power cord.
- Unplug the unit before cleaning. Clean with a damp cloth only. Do not spill liquid on the unit.
- Unplug the unit and refer servicing to qualified service personnel under the following conditions:

If the power cord or plug is damaged; if liquid has entered the unit; if the unit has been dropped or the case damaged; if the unit does not operate normally or exhibits a distinct change in performance. Adjust only those controls that are covered by the operating instructions.

Do not defeat the safety purpose of the polarised or grounding-type plug. A polarised plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wider blade or the third prong are provided for your safety. When the plug provided does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

WARNING:

THIS UNIT MUST BE EARTHED BY THE POWERCORD

UNDER NO CIRCUMSTANCES
SHOULD THE MAINS EARTH BE
DISCONNECTED FROM THE MAINS
LEAD.

This unit is capable of operating over a range of mains voltages as marked on the rear panel. Ensure correct mains voltage setting and correct fuse before connecting mains supply. Do not change mains voltage settings while mains supply is connected.

To avoid the risk of fire, replace the mains fuse only with the correct value fuse, as marked on the rear panel.

The internal power supply unit contains no user serviceable parts. Refer all servicing to a qualified service engineer, through the appropriate Focusrite dealer.

Power Connections

There is an IECmains lead supplied with the unit which should have the correct moulded plug for your country. The wiring colour code used is: For units shipped to the USA, Canada, Taiwan and Japan:

Live - Black **Neutral** - White **Earth** - Green For units shipped to any other country:

Live - Brown **Neutral** - Blue **Earth** - Green and Yellow

Signal Connections



XLR (Audio) Inputs and Outputs

All 3-pin XLR audio connectors (Output, Mic/Line Inputs) are wired as follows:

Pin 1 Screen/Chassis

Pin 2 Audio 0°

Pin 3 Audio 180°

Insert Send and Return

1/4" Jack wired as follows:

Tip Audio 0° Ring Audio 180° Sleeve Screen/Chassis

Mic IP & Line IP

Either of these inputs may be used as the main input to the ISA110.

Insert Return

This is used as the insert input point after the Mic Pre and before EQ.

Insert Send

This is used as the insert output point after the Mic Pre and before EQ.

Output

This is a balanced output after the EQ.

Getting to Know the ISA110

On

Applies power to the unit. Turn on the ISA110 before powering up devices to which the outputs are connected.



O/L LED

This LED illuminates when the peak signal level reaches or exceeds +20dB, or when the peak signal level reaches 6dB below clipping. The signal is monitored after the EQ stage.

Occasional short-duration peaks which may cause the LED to blink will not normally cause audible distortion, but if the LED is lit constantly, the level in the appropriate section of the module should be reduced to prevent overloading.

Input Stage



Two input options are provided to give compatibility with Mic or Line sources.

Mic

Mic input sensitivity is switched from -60dB to 0dB in 6dB steps. Phantom power is available on the rear panel XLR for condenser mics when +48V front panel switch is pressed.

l ine

A Line input is available on XLR, with a switched gain control giving a range of +/-18dB in 6dBsteps.

Trim

The TRIM control provides additional variable gain of 0 to 10dB.

+48V

Provides +48V powering for condenser mics when pressed.

Phase

Pressing PHASE reverses the phase of the selected input, to correct phase problems with close microphones or incorrect wiring polarity. Phase is before the Insert Send output.

FO Module

All FO

Pressing ALL EQ activates all sections of the EQ module (except the Hi and Lo Pass Filters) and also the insert return, placing the whole module in the audio path. Toggling ALL EQ allows A/B comparison of flat/EQ'd settings and insert effects.



Filter In

Switch the control from the OFF position to make the Hi and Lo Pass Filters active in the audio path.

Both filters provide 18dB/octave rolloff.

Low Pass Filter

Rolloff frequency is switch selectable at 3k9Hz, 5k6Hz, 8k2Hz, 12kHz or16kHz.

High Pass Filter

Rolloff frequency is switch selectable at 36Hz, 60Hz, 105Hz, 185Hz or 330Hz.

PARAMETRIC EO

Two separate bands of parametric EQ are provided, each with continuously variable boost/cut with centre detent, sweep control with two ranges, and variable Q. The first band covers the range 40Hz to 400Hz (120Hz to 1k2Hz when x3 is pressed) and the second band covers 600Hz to 6kHz (1.8kHz to 18kHz when x3 is pressed).



Parametric EQ In

Press in to switch the Parametric EQ into the signal path. ALL EQ must also be on for the Parametric EQ to be active.

х3

The Sweep controls have two ranges, the higher being selected when the x3 switch is pressed (frequencies shown in yellow on the panel).

SHELVING EQ


High and Low frequency shelving sections are available, each with continuously variable boost/cut with centre detent, and a six position rotary switch for selection of rolloff frequency.





Shelving EQ In

Press in to switch all the Shelving EQ into the signal path. ALL EQ must also be on for the Shelving EQ to be active.

APPLICATIONS







Specifications

Rear Panel Connectors

Insert Send

Connector: TRS Jack Signal: Balanced Operating Level: +4dBu Maximum O/P Level: +20dBu

The connector is an output from the point in the signal path before the EQ.

Insert Return

Connector: TRS Jack Signal: Balanced Operating Level: +4dBu Maximum I/P Level: +26dBu

The connector is the return or input to the signal path.

Line

Connector: XLR

Signal: Balanced (Transformer)

Operating Level: +4dBu Maximum I/P Level: +26dBu

Gain Range: +/-18dB in 6dB steps

Input Impedance: $10K\Omega$

Noise: -96dBu

THD: 0.003% with 0dBu 1kHz input

and 20Hz-22kHz bandpass filter

Mic

Connector: XLR

Signal: Balanced (Transformer)

Operating Level: +4dBu Maximum I/P Level: +26dBu

Gain Range: 0 to +60dB in 6dB steps

Input Impedance: $1k2\Omega$

Noise: 123dB EIN with 150 Ω

input resistance at 60dB of gain

THD: 0.0008%

Output

Connector: XLR

Signal: Balanced (Transformer)

Operating Level: +4dBu Maximum O/P Level: +26dBu

Signal is the transformer output stage.

Dimensions

Height 44mm (1.7")

Width 444.6mm(17.5") at rear

483mm (19") at front

Depth 309.7mm (12.2")

Accuracy:

Whilst every effort has been made to ensure the accuracy and content of this manual, Focusrite Audio Engineering Ltd makes no representations or warranties regarding the contents.

Copyright:

Copyright December 1999 Focusrite Audio Engineering Ltd. All rights reserved. No part of this manual may be reproduced, photocopied, stored on a retrieval system, transmitted or passed to a third party by any means or in any form without the express prior consent of Focusrite Audio Engineering Ltd.

Warranty:

All Focusrite products are covered by a warranty against manufacturing defects in material or craftsmanship for a period of one year from the date of purchase. Focusrite in the UK, or its authorised distributor worldwide will do its best to ensure that any fault is remedied as quickly as possible. This warranty is in addition to your statutory rights.

This warranty does not cover any of the following:

- Carriage to and from the dealer or factory for inspection or repair labour charge if repaired other than by the distributor in the country of purchase or Focusrite in the U.K.
- Consequential loss or damage, direct or indirect, of any kind, however caused
- Any damage or faults caused by abuse, negligence, improper operation, storage or maintenance

If a product is faulty, please first contact your dealer in the country of purchase; alternatively, contact the factory. If the product is to be shipped back, please ensure that it is packed correctly, preferably in the original packing materials. We will do our best to remedy the fault as quickly as possible.

Please help us to serve you better by completing and returning the Warranty Registration Card at the back of this manual. Thank you.

Focusrite Distributors

Argentina
Phone:
Fax:
Australia
Phone:
Fax:
Austria
Phone:
Fax:
Belgium
Phone:

Fax:
Belgium
Phone:
Fax:
Brazil
Phone:
Fax:

Pazzil
Phone:
Fax:
Canada
Phone:
Fax:
Chile
Phone:
Fax:
Croatia, Slovenia,
Bosnia. Macedonia

Bosma, Maccand Serbia
Phone:
Fax:
Phone:
Fax:
Egypt
Phone:
Fax:
Finland
Phone:
Fax:

France
Phone:
Fax:
Germany
Phone:
Fax:
Greece
Phone:
Fax:

Hong Kong/China

Phone: Fax: Hungary Phone: Fax: Iceland Phone: Fax: India

Phone:
Fax:
Indonesia
Phone:
Fax:
Ireland
Phone:
Fax:
Israel
Phone:
Fax:

Phone: Fax: Italy Phone: Fax: Japan Phone: Fax: DBA Systems SRL 00 54 I 545 6800 00 54 I 545 3668 Electric Factory Pty Ltd 00 61 3 9480 5988 00 61 3 9484 6708 TC Electronic Austria 0800 201 652

0800 201 652 0800 201 653 EML

00 32 11 23 23 55 00 32 11 23 21 72 Proware

00 55 11 5585 2866 00 55 11 5584 6586 **Digidesign Canada** 00 1 650 842 7900

00 1 650 842 7999 Clio Musical Productora 00 56 2 274 9621 00 56 2 294 9575

00 358 9 5123 5355 **DM2J Audio Solution**00 33 1 48 63 04 43
00 33 1 48 63 02 01 **TC Electronic Deutschland**

00 49 40 531 08 399 00 49 40 531 08 398 **Bon Studio S.A.** 00 30 1 3809605-8 00 30 1 3827868

Digital Media Technology 00 852 2721 0343 00 852 2366 6883

Absolute 00 361 252 0196 00 361 341 0272 Exton

00 354 551 2555 00 354 562 6490 **R & S Electronics**

R & S Electronics 00 91 22 636 9147 00 91 22 636 9691 **Paradi**

Paradi 00 6221 831 8388 00 6221 8370 3473

CTI - Control Techniques Ireland 00 353 1 454 5400

00 353 1 454 5400 Sontronics 00 972 3 570 5223 00 972 3 619 9297 Grisby Music Professional

00 39 0 71 7108471 00 39 0 71 7108477 **All Access Inc** 00 81 52 443 5537 00 81 52 443 7738 Korea
Phone:
Fax:
R. O. Maldives
Phone:
Fax:
Mexico
Phone:
Fax:
Netherlands
Phone:
Fax:
New Zealand

Phone: Fax: New Zealand Phone: Fax: Norway Phone: Fax:

Phone: Fax: Portugal Phone: Fax: Romania

Poland

Phone: Fax: **Russia** Phone: Fax:

Singapore/Malaysia

Phone: Fax: South Africa Phone: Fax: Spain Phone: Fav. Sri Lanka Phone: Fav. Sweden Phone: Fax: Switzerland Phone: Fax: Taiwan Phone: Fax: Thailand Phone:

Fax: Turkey Phone:

Fax: United Kingdom

Phone: Fax: USA Phone:

Fax: Venezuela Phone:

Vietnam Phone: Fax:

Fax:

Best Logic Sound Co 00 82 2 515 7385 00 82 2 516 7385 Island Acoustics 00 960 32 0032 00 960 31 8624 Vari

Vali 00 525 604 6946 00 525 605 9656 **Total Audio BV** 00 31 20 4476447 00 31 20 4476464 **Protel**

00 64 4 801 9494 00 64 4 384 2112 **Lydrommet** 00 47 22 80 94 50 00 47 22 80 94 60

Hexagon 00 48 22 44 66 99 00 48 22 44 83 55 Caius Tecnologias 00 35122 208 6009 00 35122 208 5969

00 35122 208 5969

A.F. Marcotec (Bucharest)
00 40 1 337 1254

AT Trade

00 7 095 956 1105 00 7 095 956 6882 Team 108 Technical Services

Private Ltd 00 65 748 9333 00 65 747 7273

00 46 31 7069110 Bleuel Electronic ag 00 41 1 751 7550 00 41 1 751 7500 DMT (Taiwan) Ltd 00 886 2 25164318 00 886 2 25159881 KEC

00 46 31 7069050

00 66 2 222 8613/4 00 66 2 225 3173 Imaj Music Yapim VE Organizasyon Ticaret A.s 00 90 212 216 7180

00 90 212 216 7180 00 90 212 216 7189 Focusrite Audio Engineering Ltd

+44 (0) 1494 462246 +44 (0) 1494 459920 **Digidesign (San Francisco)** 00 1 650 842 7900 00 1 650 842 7999

C&M Audio 00 58 2 263 8790/264 2050/

266 0466 00 58 2 267 4319 **Vistar**

00 84 4 824 3058 00 84 4 825 0099

Focusrite audio engineering

Focusrite Audio Engineering Ltd, Lincoln Road, High Wycombe, Bucks HP12 3FX England Tel: +44 (0)1494 462246 FAX: +44 (0)1494 459920 e-mail: sales@focusrite.com www.focusrite.com