TUBE-TECH ME 1B mid equalizer

DESCRIPTION

The **TUBE-TECH program equalizer ME 1A** contains a passive filter and a tube (valve) based amplifier to restore the loss from the filter.

The filter has a low frequency peak section with 5 selective frequencies, a mid frequency dip section with 11 selective frequencies, and a high frequency peak section with 5 selective frequencies.

The filter is placed directly after the input transformer, therefore eliminating noise from the amplifier when boosting either low- or high frequencies.

The amplifier consists of two tubes (valves) in push-pull configuration (one ECC 83 as the pre-amp, and one ECC 82 as the output stage), and an output transformer.

Both input and output are balanced (600Ω) and fully floating.

The in/out key switches the equalization in and out without clicks and changes in level, while the amplifier remain in the signal path.

(040319)

CONTROLS:

LOW FREQUENCY

SECTION: The low frequency section consists of a **PEAK** control and a

LOW FREQUENCY switch located to the left.

<u>PEAK:</u> The **PEAK** control is continuously variable from 0 dB to +10 dB.

It is of the bell type.

LOW

FREQUENCY: The **LOW FREQUENCY** switch determines at which

frequency the maximum peaking is obtained.

There is a choice of 5 frequencies:

0.2, 0.3, 0.5, 0.7 and 1 kHz.

MID FREQUENCY

SECTION: The mid frequency section consists of a **DIP** control and a

MID FREQUENCY switch located to the left.

<u>DIP:</u> The **DIP**-control is continuously variable from 0 dB to -10 dB.

It is of the bell type.

(050504)

MID

FREQUENCY: The MID FREQUENCY switch determines at which

frequency the maximum peaking is obtained.

There is a choice of 11 frequencies:

0.2, 0.3, 0.5, 0.7, 1, 1.5, 2, 3, 4, 5 and 7 kHz.

HIGH FREQUENCY

SECTION: The high frequency section consists of a **PEAK** control and a

HIGH FREQUENCY switch located to the left.

<u>PEAK:</u> The **PEAK**-control is continuously variable from 0 dB to +8 dB.

It is of the bell type.

HIGH

FREQUENCY: The **HIGH FREQUENCY** switch determines at which

frequency the maximum peaking is obtained.

There is a choice of 5 frequencies:

1.5, 2, 3, 4 and 5 kHz.

IN/OUT: The in/out key switches the filter in and out of the signal path.

The amplifier remains in the circuit.

(040319)